

THE LENGTH OF EACH DAM SHOULD BE ESTIMATED FROM THE TOP OF THE STARTING BANK, DOWN TO THE TOE OF THE SLOPE, ACROSS THE CHANNEL, AND UP THE OPPOSING SLOPE. THIS SHOULD BE ESTIMATED ALONG THE OUTER EDGE OF EACH AQUADAM. ADD 5FT EXTRA AT EACH END THAT IS AT THE TOP OF THE BANK.

